ASSEMBLY INSTRUCTION

PART LIST:

The pictures are for reference only. Please note that for a 240 cm Christmas tree, the set includes 4 sections with branches for assembly.

Stand	Bolts	Bottom Section	Middle Section	Top Section
				
1pc	3 pcs	1pc	1pc	1pc

TREE ASSEMBLY:



Please check that all parts are present using part list section



Place the stand in the shape of "X"



Screw in 1 bolts to the base hole,and don't screw too tight



Insert bottom section into the stand,turn the screws to fix the tree



Open bottom section



Insert middle section



Insert top section



Please remember to open the small branches and tips fully,give the tree a fuller look(Please See "Shaping Instructions" Below)

SHAPING INSTRUCTION:

How to fluff the branches

Shaping the tree branches is the last step of assembly. The care and attention given to this final process will result in a genuinely beautiful and appealing holiday centerpiece.



Every tree style is shipped from the factory with the tips of each branch compressed to the center.



Each branch tip must be shaped to it's proper position to give the tree a natural look. Spread tips away from the branch gently.



Each individual tip should then be spread out separately. Tips should then be bent slightly upward to add a more natural looking appearance.

Tips !

Fig.3 shows a typical tree branch after shaping. Branch tips should be carefully pressed back toward center tip when tree is disassembled for storage in original carton.